





Diesel Systems

-  Modern Systems
-  Conventional Systems




Engine Info

- 35 FAS Keys
- 54 engine types
- Construction, Power Gensets



Engines

D1146T	DL08 STAGE5
D1146TI	DL08 T4F
D18 Stage 5	DV11
D2366T	DV15
D2366TI	DV15T
D24 Stage 5	DV15TC
D2842L	DV15TI
D2848LE	DX12 EU4
D2848LE-Marine	DX12 EU6
D34	DX22
DB33TI	DX22 Tier 2
DB58	G2 D18 STAGE5
DB58NA	G2 D24 STAGE5
DB58TI	G2 D34 STAGE5
DE08TIS	G2-D34
DE12TI	G2-D34 T4F
DE12TIB	GL08
DE12TIS	GL11K
DE12TIS Euro 2	V2-8TC
DL06	V2-8TCI
DL06 STAGE5	DL08
DL06 T4F	






Cross Reference

Doosan Number	Bosch Number
400912-00093	H106674414
400912-00113	H106675492
150120-00014	0445226107
150120-00086	0445226201
150120-00087	0445223015
150120-00088	0445224134
150120-00096	0445226204
300628-00008	0444022031
300628-00083	0444031006
300628-00106	0444042082
300628-00302	0444110003
300628-00628B	0444042198
300628-00629B	0444042205
300628-00672	0444042259
300630-00013	0444033004
300630-00015	0444043059
300630-00044B	0444063017
301318-00007	0281006102
400903-00031	0445120258
400903-00032	0445120259
400903-00036	0445120295
400903-00045	0445120278
400903-00046	0445120268
400903-00104	0445120376
400903-00157	0445120450
400903-00174	0445120547
400903-00203	0445120566
400903-00223	0445110968
400903-00225	0445111003
400903-00233	0445120564
400912-00007	0445020157
400912-00008	0445020132
400912-00092	H106675490

Doosan Number	Bosch Number
400912-00277	0445020253
400912-00558	0445020337
400912-00572	0445020541
400912-00573	0445020542
420103-00504A	0445130255
420103-00505A	0445130254
420103-00506B	0445130256
430230-00009	F00RJ02742
430230-00012	F00RJ02857
65.10401-7002	0445120041
65.10401-7005	0445120145
65.10401-7006	0445120146
65.10415-0001	F00RJ00240
65.10501-7002	0445020032
65.10501-7006	0445020127
65.10501-7007	0445020128
65.10601-6001	0445226032
65.10601-6003	F00R001778
65.10601-6004	0445226057
65.10601-6007	0445226077
65.10601-6008	0445226073
65.10601-6009	F00R002797
65.10601-6010	F00R002802
65.11101-7301	0402618813
65.11101-7359	0402648718
65.11101-7425	0402648721
65.11101-7662	0402648708
65.15301-7001	0444023015
65.27103-7008	0281002662
65.27405-6008	0280130092
65.27423-7003	0281002209
65.27427-7001	0261230112
65.27444-7001	0281002576
65.10101-7053	0432231669




Application Guide

Engine	Emission	OE Number	IAM Number	Product
DL06	Tier4	300628-00672	0444042259	Supply module
DL06	EU4/5	400903-00046	0445120268	Injector
DL06	EU4/5	65.10601-6007	0445226077	Distributor Tube
DL06	EU4/5	65.10401-7004A	0445120080	Injector
DL06	EU4/5	65.10501-7005A	0445020067	Radial Piston Pump
DL06	EU4/5	300628-00008	0444022031	Supply module
DL06	EU4/5	65.15301-7001	0444023015	Dosing module
DL06	Tier4	300628-00083	0444031006	Metering unit
DL06	Tier4	300630-00013	0444033004	Injection unit
DL06	Tier4	150120-00014	0445226107	Distributor Tube
DL06	Tier4	400903-00036	0445120295	Injector
DL06	Tier4	400912-00030A	0445020152	Radial Piston Pump
DL06	Tier3	65.10501-7007	0445020128	Radial Piston Pump
DL06	EU3 & Tier3	65.10601-6004	0445226057	Distributor Tube
DL06	EU3 & Tier3	65.10401-7004A	0445120080	Injector
DL06	EU3 & Tier3	65.10501-7005A	0445020067	Radial Piston Pump
DL08	Tier 5	300630-00044B	0444063017	Dosing module
DL08	Tier 5	400912-00528	0445020614	Radial Piston Pump
DL08	Tier 5	150120-00086	0445226201	Distributor Tube
DL08	Tier4	150120-00014	0445226107	Distributor Tube
DL08	Tier4	400903-00157	0445120450	Injector
DL08	Tier4	400912-00030A	0445020152	Radial Piston Pump
DL08	EU6	400903-00045	0445120278	Injector
DL08	EU6	400912-00007	0445020157	Radial Piston Pump
DL08	EU6	65.10601-6008	0445226073	Distributor Tube
DL08	EU6	300628-00106	0444042082	Supply module
DL08	EU6	300630-00015	0444043059	Dosing module
DL08	Tier 4f	300628-00628B	0444042198	Supply module




Application Guide

Engine	Emission	OE Number	IAM Number	Product
D1146T			H105160437	Nozzle And Holder Assy
D1146TI			H106671996	Injection-Pump Assembly
D1146TI			H106673420	Injection-Pump Assembly
D1146TI			H106674412	Injection-Pump Assembly
D2366T			H106675445	Injection-Pump Assembly
D2366TI			H106671903	Injection-Pump Assembly
D2366TI			H106672992	Injection-Pump Assembly
D2848LE			0401848828	Injection-Pump Assembly
D2848LE-Marine			0402648713	Injection-Pump Assembly
D2842L			0401840776	Injection-Pump Assembly
V2-8TC			0401848830	Injection-Pump Assembly
V2-8TC			0402648791	Injection-Pump Assembly
V2-8TC			0402648796	Injection-Pump Assembly
V2-8TC		65.10101-7053	0432231669	Nozzle And Holder Assy
V2-8TC			0433171169	Nozzle
V2-8TCI			0432231657	Nozzle And Holder Assy
DV11	EU4/5	65.10401-7006	0445120146	Injector
DV11	EU4/5	65.10501-7002	0445020032	Radial Piston Pump
DV11	EU4/5	65.10601-6009	F00R002797	Distributor Tube
DV11	EU4/5	65.10601-6010	F00R002802	Distributor Tube
DV11	EU4/5	300628-00008	0444022031	Supply module
DV11	EU4/5	65.15301-7001	0444023015	Dosing module
DL06	Stage V	300630-00044B	0444063017	Dosing module
DL06	Stage V	400912-00528	0445020614	Radial Piston Pump
DL06	Stage V	400903-00174	0445120547	Injector
DL06	Stage V	150120-00086	0445226201	Distributor Tube
DL06	Tier4	150120-00014	0445226107	Distributor Tube
DL06	Tier4	400903-00104	0445120376	Injector
DL06	Tier4	400912-00030A	0445020152	Radial Piston Pump
DL06	Tier4	300628-00106	0444042082	Supply module
DL06	Tier4	300630-00015	0444043059	Dosing module
DL06	Tier4	300628-00106	0444042082	Dosing module
DL06	EU6 (no LTC)	400903-00046	0445120268	Injector




Application Guide

Engine	Emission	OE Number	IAM Number	Product
DL08	EU3 & Tier3	65.10601-6001	0445226032	Distributor Tube
DL08	EU3 & Tier3	65.10401-7001C	0445120040	Injector
DL08	EU3 & Tier3	65.10501-7001A	0445020031	Radial Piston Pump
DL08	EU4/5	300628-00008	0444022031	Supply module
DL08	EU4/5	65.15301-7001	0444023015	Dosing module
DV15		65.11101-7301	0402618813	Injection-Pump Assembly
DV15		65.11101-7359	0402648718	Injection-Pump Assembly
DV15		65.11101-7425	0402648721	Injection-Pump Assembly
DV15		65.11101-7662	0402648708	Injection-Pump Assembly
DV15T			0402648702	Injection-Pump Assembly
DV15T			0402648974	Injection-Pump Assembly
DV15TC			0402648707	Injection-Pump Assembly
DV15TC			H106872417	Injection-Pump Assembly
DV15TI			0401848832	Injection-Pump Assembly
D18	STAGE5	400903-00223	0445110968	Injector
G2 D18	STAGE5	400912-00572	0445020541	Radial Piston Pump
G2 D18	STAGE5	150120-00087	0445223015	Distributor Tube
G2 D18	STAGE5	420103-00504A	0445130255	Fuel Return Line
D24	STAGE5	400903-00223	0445110968	Injector
G2 D24	STAGE5	150120-00088	0445224134	Distributor Tube
G2 D24	STAGE5	420103-00505A	0445130254	Fuel Return Line
G2 D24	STAGE5	400912-00572	0445020541	Radial Piston Pump
D34		400903-00225	0445111003	Injector
G2 34	STAGE5	150120-00088	0445224134	Distributor Tube
G2 D34		300628-00302	0444110003	Supply module
G2 D34		300630-00015	0444043059	Dosing module
G2 D34	STAGE5	420103-00506B	0445130256	Fuel Return Line
G2 D34	STAGE5	400912-00573	0445020542	Radial Piston Pump
G2-D34		300630-00044B	0444063017	Dosing module
G2-D34	Tier 4f	300628-00628B	0444042198	Supply module
G2-D34	Tier 4f	300628-00629B	0444042205	Supply module
GL08	EU6	300628-00106	0444042082	Supply module
GL08	EU6	300630-00015	0444043059	Dosing module
GL11K	EU6	300628-00106	0444042082	Supply module
GL11K	EU6	300630-00015	0444043059	Dosing module




Application Guide

Engine	Emission	OE Number	IAM Number	Product
DB58TI			H101605979	Injection-Pump Assembly
DB58TI			H105025400	Nozzle
DB58TI			H105025420	Nozzle
DB58TI			H105160532	Nozzle And Holder Assy
DB58TI			H105160533	Nozzle And Holder Assy
DB58TI			H105160542	Nozzle And Holder Assy
DV11	Tier3	400912-00008	0445020132	Radial Piston Pump
DV11	EU3 & Tier3	65.10401-7002	0445120041	Injector
DV11	EU3 & Tier3	65.10501-7002	0445020032	Radial Piston Pump
DV11	EU3 & Tier3	65.10601-6003	F00R001778	Distributor Tube
DV11	EU3 & Tier3	65.10601-6002A	F00R001773	Distributor Tube
DV11 V-type		400903-00032	0445120259	Injector
DX22		150120-00096	0445226204	Distributor Tube
DX22 TI2		400912-00558	0445020337	Radial Piston Pump
DX22	Tier2	400903-00233	0445120564	Injector
DX12	EU4	300630-00044B	0444063017	Dosing module
DX12	EU6	400912-00558	0445020337	Radial Piston Pump
DX12	EU6	400903-00203	0445120566	Injector
DB33TI			H105017280	Nozzle
DB33TI			H105118675	Nozzle And Holder Assy
DE12TIS			H105017933	Nozzle
DE12TIS			H105025285	Nozzle
DE12TIS			H108622413	Injection-Pump Assembly
DE12TIS	EU2		H108622400	Injection-Pump Assembly
DE08TIS		400912-00092	H106675490	Injection-Pump Assembly
DE08TIS		400912-00113	H106675492	Injection-Pump Assembly
DE12TI			H105101852	Nozzle And Holder Assy
DE12TI			H105101853	Nozzle And Holder Assy
DE12TI			H105160487	Nozzle And Holder Assy
DE12TI			H106671926	Injection-Pump Assembly
DE12TI			H106674413	Injection-Pump Assembly
DE12TI			H106675437	Injection-Pump Assembly
DE12TI			H106675459	Injection-Pump Assembly
DE12TI			H106675465	Injection-Pump Assembly



Application Guide

Engine	Emission	OE Number	IAM Number	Product
DL06	EU6 (no LTC)	65.10601-6007	0445226077	Distributor Tube
DL06	EU6 (no LTC)	65.10501-7005A	0445020067	Radial Piston Pump
DL06	EU6	300628-00106	0444042082	Supply module
DL06	EU6	300630-00015	0444043059	Dosing module
DL06	Tier4	300630-00015	0444043059	Dosing module
DL06	Tier4	300628-00628B	0444042198	Supply module
DL06	Tier4	300628-00629B	0444042205	Supply module
DL08	Tier 4f	300628-00629B	0444042205	Supply module
DL08	Tier 4f	300628-00672	0444042259	Supply module
DL08	EU4/5	400903-00045	0445120278	Injector
DL08	EU4/5	400912-00007	0445020157	Radial Piston Pump
DL08	EU4/5	65.10401-7005	0445120145	Injector
DL08	EU4/5	65.10601-6008	0445226073	Distributor Tube
DL08	Tier4	300628-00083	0444031006	Metering unit
DL08	Tier4	300630-00013	0444033004	Injection unit
DL08	Tier4	150120-00014	0445226107	Distributor Tube
DL08	Tier4	400903-00031	0445120258	Injector
DL08	Tier4	400912-00030A	0445020152	Radial Piston Pump
DL08	Tier3	65.10501-7006	0445020127	Radial Piston Pump
DB58			H101605995	Injection-Pump Assembly
DB58			H105025065	Nozzle
DB58NA			H101605996	Injection-Pump Assembly
DB58NA			H105025138	Nozzle
DB58NA			H105160465	Nozzle And Holder Assy
DE12TIB		400912-00093	H106674414	Injection-Pump Assembly
DL06	CN Phase3	400903-00046	0445120268	Injector
DL06	CN Phase3	65.10501-7007	0445020128	Radial Piston Pump
DL06	CN Phase3	65.10601-6007	0445226077	Distributor Tube
DL08	CN Phase3	400903-00045	0445120278	Injector
DL08	CN Phase3	400912-00277	0445020253	Radial Piston Pump
DL08	CN Phase3	65.10601-6008	0445226073	Distributor Tube